



---

**FORGE PORTAL FOR BUSINESS AVIATION  
REFERENCE GUIDE**

---

Airtime SaaS v2.2.B1

## Table of Contents

Table of Contents .....	1
1. Text Weather .....	3
2. Passenger Weather .....	5
3. Oceanic Tracks .....	7
4. Datalink Uplink Messaging.....	9
5. Graphical Weather Map Overlay .....	10
6. Datalink Logs .....	11

*(Intentionally left blank)*

## **MyGDC.com Datalink Features on Forge Dashboard – Feb 2025 | Airtime SaaS v2.2.B1**

To all our Honeywell Forge Dashboard users,

Honeywell announces MyGDC.com Datalink features that are incorporated on the Forge Dashboard as part of the release Airtime SaaS v2.2.B1 (Feb 2025). The detailed description of these new features along with comparison to MyGDC.com follows:

*(Intentionally left blank)*

# 1. Text Weather

Text Weather available in MyGDC.com at:  
**mygdc.com> Weather> Text**




Figure 1a: Text Weather on MyGDC.com

Text weather is available now in the Forge Dashboard at:  
**bga.honeywellforge.com> Grid menu > Weather:**




Figure 1b-i: Text Weather on the Forge Dashboard

bga-stg.honeywellforge.com/weather?view=terminalweather

12:18 UTC 07:18 EST Viewing as h375358 (alexander.ramirez@honeywell.com)

**HONEYWELL FORGE**

**Text Weather Options**

- Terminal Weather 3
- NOTAMs
- FIR NOTAMs
- SIGMETs
- AIRMETs
- Winds Aloft
- Smart NOTAMs
- PAX Weather
- Oceanic Tracks

**Terminal Weather**

Change Selections Highlight  Go Clear

KLAS - METAR

KLAS METAR 211156Z 13003KT 10SM CLR 11/M04 A3017 RMK AO2 SLP208  
 T01061044 10156 20100 51004  
 METAR 211056Z 05008KT 10SM SCT250 11/M05 A3016 RMK AO2 SLP205  
 T01111050  
 METAR 210956Z 08009KT 10SM FEW250 12/M05 A3017 RMK AO2 SLP206  
 T01171050

KLAS - TAF

KLAS TAF 211120Z 2112/2218 35009KT P6SM BKN250  
 FM211700 03010KT P6SM SKC  
 FM220200 VRB05KT P6SM FEW250

Time UTC	12	13	14	15	16	17	18	19	20	21	22	23	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
Flight Rule	VFR			VFR									VFR																		

KLAS - NOTAM

US Domestic NOTAMs (65):

02/165 - ILAS 02/165 LAS RWY 26R PAPI U/S 2502211053-2502282000EST

Figure 1b-ii: Text Weather on the Forge Dashboard

(Intentionally left blank)

## 2. Passenger Weather

Passenger Weather available in MyGDC.com at:  
**mygdc.com > Weather > Pax Wx**




Figure 2a: Passenger Weather on MyGDC.com

Passenger Weather is available now in the Forge Dashboard at:  
**bga.honeywellforge.com > Grid menu > Weather > Pax Wx**




Figure 2b-i: Passenger Weather on the Forge Dashboard




Figure 2b-ii: Passenger Weather on the Forge Dashboard

(Intentionally left blank)

### 3. Oceanic Tracks

Oceanic Tracks available in MyGDC.com at:  
**mygdc.com> Resources> Tools and Resources> Oceanic Tracks**




Figure 3a-i: Oceanic Tracks on MyGDC.com




Figure 3a-ii: Oceanic Tracks on MyGDC.com



Oceanic Tracks are available now in the Forge Dashboard at:  
**bga.honeywellforge.com**> Grid menu > Weather > Oceanic Tracks




Figure 3b-i: Oceanic Tracks on the Forge Dashboard




Figure 3b-ii: Oceanic Tracks on the Forge Dashboard

#### 4. Datalink Uplink Messaging

Datalink Uplink Messaging available in MyGDC.com at:  
**mygdc.com > Resources > Datalink Logs > Send Message**




Figure 4a: Datalink Uplink Messaging in MyGDC.com

Datalink Uplink Messaging is available in the Forge Dashboard at:  
**bga.honeywellforge.com > Fleet Real-time > Fleet Status > Message box**




Figure 4b: Datalink Uplink Messaging in the Forge Dashboard

## 5. Graphical Weather Map Overlay

Graphical Weather Map Overlay is available in MyGDC.com at:  
[mygdc.com](https://mygdc.com) > **Flight Planning** > **New Flight Plan** > **Map** > **Cloud icon**




Figure 5a: Graphical Weather Map overlay on MyGDC.com

Graphical Weather Map Overlay is available now in the Forge Dashboard at:  
[bga.honeywellforge.com](https://bga.honeywellforge.com) > **Fleet Real-time** > **Map** > **Cloud icon**





Figure 5b: Graphical Weather Map Overlay on the Forge Dashboard

## 6. Datalink Logs

Datalink Logs are available in MyGDC.com at:  
**mygdc.com > Resources > Datalink Logs**




The screenshot shows the MyGDC.com website interface. At the top, there is a navigation bar with 'Resources' highlighted. A red circle '1' is placed over the 'Resources' link. Below the navigation bar, a banner message states: 'IMPORTANT: The mygdc.com website and Forge Flight Planning Services will be discontinued by April 30, 2025'. A 'CLICK FOR DETAILS' button is next to it. The main content area is titled 'Datalink Log'. There is a search bar with 'Entered Aircraft:' and a 'Change' button. Below this, there are tabs for 'Datalink Log', 'Position Reports', and 'Text Messages'. The 'Datalink Log' tab is selected. There are radio buttons for 'Latest Activity Log' (selected), 'Search Log', and 'Log by Flight Leg'. Below this, the aircraft 'N161B - Latest Activity Log' is shown. A table displays the Datalink Log Report with columns: Date/Time- (UTC), Message Type, Details, Receiver Station / Network / Location, Comm Mode, and Delivery Status. The table contains two rows: one for 'In Report - Park at gate' and one for 'Landing Report', both with a 'Success' status.

Date/Time- (UTC)	Message Type	Details	Receiver Station / Network / Location	Comm Mode	Delivery Status
	In Report - Park at gate			Satellite	Success
	Landing Report			Satellite	Success

Figure 6a: Datalink Logs on MyGDC.com

Datalink Logs are available in the Forge Dashboard at:  
**bga.honeywellforge.com > Aircraft > Analytics > Datalink Logs**



The screenshot shows the Forge Dashboard interface. The top navigation bar includes 'DASHBOARDS', 'Fleet', and 'Aircraft' (highlighted with a red circle '1'). The main content area is titled 'Datalink' (highlighted with a red circle '3'). It shows a summary of message status: '0 failed message(s)', '7 successful message(s)', and '0 in-progress message(s)'. There are filters for 'Message Type', 'Delivery Status', and 'Comm Mode', all set to 'All'. A 'Text' field contains 'Hint text'. Below the filters are 'CLEAR' and 'SEARCH' buttons. A table displays the Datalink Logs with columns: DATE / TIME (UTC), MESSAGE TYPE, DETAILS, RECEIVER STATION / NETWORK / LOCATION, COMM MODE, and DELIVERY STATUS. The table contains two rows, both with a 'Success' status.

DATE / TIME (UTC)	MESSAGE TYPE	DETAILS	RECEIVER STATION / NETWORK / LOCATION	COMM MODE	DELIVERY STATUS
					Success
					Success

Figure 6b: Datalink Logs on the Forge Dashboard

*(Intentionally left blank)*